



## NEROLAC ZINC YELLOW PRIMER



# NEROLAC

Colours that Care

### PRODUCT DESCRIPTION

Nerolac Zinc Yellow Primer provides excellent rust protection to metal surfaces keeping them corrosion free and beautiful for longer time.

### PERFORMANCE FEATURES & BENEFITS

 <p>High protection against rust</p>	 <p>Stronger than ordinary metal primer</p>
 <p>Zinc Phosphate based</p>	 <p>Excellent adhesion</p>
 <p>Value for money</p>	

### SURFACE PREPARATION

1. Ensure the surface is clean, dry & free from all defective or poorly adhering material like dirt, grease, wax, etc.
2. Remove all loose or poorly adhering materials by rubbing down using emery paper 180 and wipe clean.
3. Apply a coat of Nerolac Zinc Yellow Primer followed by Putty (if required) to level the dents and make the surface uniform by using emery paper 180 & wipe clean.
4. Apply again a coat of Nerolac Zinc Yellow Primer & smoothen the surface with emery paper 320 & wipe clean.
5. Then apply two coats of Synthetic Enamels like Nerolac Synthetic Enamel, Nerolac 10 in 1 PU Enamel, Goody Synthetic Enamel, Nerolac Enamel, etc. with min. 8 h in between the coats.

### RECOMMENDED USAGE

Area of use: Interior and Exterior metal surface.

### RECOMMENDED SYSTEM FOR APPLICATION: METAL SURFACES

1. Primer (Nerolac Zinc Yellow Primer) (1 coat), Dry for Min 8 h
2. Putty (Nerolac Knifing Paste Filler) if required, Dry for 6-8 h.
3. Primer (Nerolac Zinc Yellow Primer) (1 coat), Dry for Min 8 h.
4. Top Coat (Synthetic Enamels like Nerolac Synthetic Enamel, Nerolac 10 in 1 PU Enamel, Goody Synthetic Enamel, Neromin Enamel, etc.), (2 coats), Dry for Min. 8 h in between the coats.

Note - Always apply two coats of this primer for the desired performance.

### PRECAUTIONS

1. Refer to the MSDS of "Nerolac Zinc Yellow Primer" for handling, safety measures & precautions.
2. Store in well ambient conditions, ventilated locations & away from the source of ignition and fire
3. Keep away from children.
4. In case of eye/skin contact, wash with plenty of water.
5. Inhalation / Injection will cause danger. In case, move to fresh air & consult medical practitioners in both the cases.
6. Do not apply when ambient temperature might drop to level below 10°C within 4 hrs of application.
7. New plaster should be allowed to cure for minimum 12 weeks.
8. Avoid extra thinning for better results.
9. The container must be tightly closed when not in use. Stir well and strain before use.
10. Use safety equipment's like rubber or polythene gloves, safety goggles / glasses & face mask.

## TECHNICAL DATA



## POST APPLICATION INSTRUCTIONS

For removing stains sponge clean with a mild soap solution and wipe clean. Ensure a drying time of 1 week before Cleaning.



### SAFETY FEATURES

Flammable.



### PACK SIZE

500 ml, 1 L, 4 L, 10 L, 20 L



### SHELF LIFE

2 years from the date of manufacture in original tightly closed containers away from direct sunlight and excessive heat

## DISCLAIMER

The product information and application details given by the company has been provided in good faith and is meant to serve only as a general guideline during usage. The performance claims made are based on the tests carried out under controlled conditions and our past experience with the type of products, therefore actual performance will depend on local factors prevailing at that point of time. Users are advised to carry-out sample tests by taking trials to ensure the suitability of products for their requirement, prior to full-scale usage of our products.

The company is not liable for factors beyond its control such as application during adverse climatic conditions, use of improper application tools/techniques and surface preparation, any structural defects or the inferior quality of materials other than paints. The warranty/guarantee clauses shall accordingly be amended.